CRIN1-14 Common Rail 0445120044 Fuel Injection PDF



INJECTOR

120 series



CRIN1-14 Common Rail 0445120044 Fuel Injection PDF

Content

1. 0445120044 Injector Introduction	2
1.1. 0445120044 Injector Basic Information	2
1.2. 0445120044 Injector Common Part Number	2
1.3. 0445120044 Injector Matching Information	2
1.4. 0445120044 Injector Parameter	4
1.5. 0445120044 Injector Specifications and Dimensions	4
1.6. 0445120044 Injector Customized Service	4
1.7. 0445120044 Injector Packing List and Package Size	5
1.8. 0445120044 Injector Quality Control	6
1.9. 0445120044 Injector Testing Standard and Certificate	7
1.10. 0445120044 Injector Warranty Instructions	7
1.11. 0445120044 Injector Manufacturer	8
2. 0445120044 Injector Technical Support	8
2.1. 0445120044 Injector Part Number Location	8
2.2. 0445120044 Injector Application Scenarios	8
2.3. 0445120044 Injector Installation	9
2.4. 0445120044 Injector Reasons for Not Working Normally	10
2.5. 0445120044 Injector Causes of Damage	10
2.6. 0445120044 Injector Technical Support Obtaining Methods	11
3. 0445120044 Injector Purchase and Delivery	11
3.1. 0445120044 Injector Purchase Payment Term	11
3.2. 0445120044 Injector Main Sales Markets	11
3.3. 0445120044 Injector Declaration Requirements	11
3.4. 0445120044 Injector Shipping Ways	11
3.5. 0445120044 Injector Lead time	11
3.6. 0445120044 Injector Logistics Time for Destination Out of China's Areas	11
3.7. 0445120044 Injector Packing	12
4. 0445120044 Injector Storage Standard	13
5. Company Information	14
5.1. Company Introduction	14
5.2. Contact Information	15
6. Copyright Policy	15



CRIN1-14 Common Rail 0445120044 Fuel Injection PDF

1. 0445120044 Injector Introduction

1.1. 0445120044 Injector Basic Information

Title	Common Rail CRIN1-14/16 Series 0445120044 Fuel Injection OE 51 10100 6049	Quality
SKU 1	G1W20445120044	China Made New
SKU 2	W20000B2B120044	Cililla Made New

1.2. 0445120044 Injector Common Part Number

(1) Injector Exchange Information

Injector Part Number	Universal Part Number	Re-manufactured Part Number		
0445120044	0445120024	0 986 435 527		

(2) Injector Application Information

Injector part Number	MAN Car Number							
0445120044	51 10100 6049	/	/	/	/	/		
0445120024	51 10100 6016	51 10100 6027	51 10100 6049	51 10100 6043	/	/		
0 986 435 527	51 10100 4043	51 10100 6043	51 10100 6027	51 10100 6049	51 10100 6016	51 10100 9049		

(3) Injector Part Number Common Writing

0445120044, 0 445 120 044, 0445 120 044, 0445120 044, 0 445120044, 0 445120 044, 0445120024, 0 445 120 024, 0445120 024, 0 445120024, 0 445120 024, 0 986 435 527

1.3. 0445120044 Injector Matching Information

Vehicle brand	Series	Car Model	Engine Model	Production date	Power (KW)	Horse power	Emission Standards	Emissions (L)	Cylinder	Power Source (V)
MAN	TGA 18	TGA 18.480 F, FA	D 2876 LF12	2002/10- 2006/09	353	480	1	12.8	6	24
MAN	TGA 18	TGA 18.480 FC, FK, FL	D 2876 LF12	2003/07- 2006/09	353	480	/	12.8	6	24
MAN	TGA 18	TGA 18.530 F, FL	D 2876 LF13	2002/11- 2004/09	390	530	/	12.8	6	24
MAN	TGA 18	TGA 18.530 FC, FK, FL	D 2876 LF13	2002/10- 2006/09	390	530	/	12.8	6	24
MAN	TGA 26	TGA 26.480 DA	D 2876 LF12	2002/09- 2006/09	353	480	Euro 3	12.8	6	24
MAN	TGA 26	TGA 26.480 FD	D 2876 LF12	2003/06- 2006/09	353	480	Euro 3	12.8	6	24
MAN	TGA 26 t	TGA 26.480	D 2876 LF12	2003/05- 2006/09	353	480	Euro 3	12.8	6	24



truck fuel injec		FN, FP, FV		Car			3	((/	(()	
MAN	TGA 26	TGA 26.480 FN, FP, FV	D 2876 LF12	2003/07- 2005/06	353	480	Euro 3	12.8	6	24
MAN	TGA 26	TGA 26.530 DA	D 2876 LF13	2004/05- 2004/09	390	530	Euro 3	12.8	6	24
MAN	TGA 26	TGA 26.530 FD	D 2876 LF13	2002/10- 2006/09	390	530	Euro 3	12.8	6	24
MAN	TGA 26	TGA 26.530 FN, FP, FV	D 2876 LF13	2002/09- 2005/06	390	530	Euro 3	12.8	6	24
MAN	TGA 26	TGA 26.530 FN, FP, FV	D 2876 LF13	2002/11- 2006/09	390	530	Euro 3	12.8	6	24
MAN	TGA 32	TGA 32.480 FFD	D 2876 LF12	2004/05- 2006/01	353	480	Euro 3	12.8	6	24
MAN	TGA 32	TGA 32.530 DA	D 2876 LF13	2004/05- 2004/09	390	530	Euro 3	12.8	6	24
MAN	TGA 33	TGA 33.480 DA	D 2876 LF12	2002/10- 2006/09	353	480	Euro 4	12.8	6	24
MAN	TGA 33	TGA 33.480 FD- WW	D 2876 LF12	2003/06- 2009/03	353	480	Euro 4	12.8	6	24
MAN	TGA 33	TGA 33.480 FD- WW	D 2876 LF25	2006/07- 2009/03	353	480	Euro 4	12.8	6	24
MAN	TGA 33	TGA 33.480 FDA- WW	D 2876 LF12	2003/08- 2009/03	352	480	Euro 4	12.8	6	24
MAN	TGA 33 t	TGA 33.530 DF	D 2876 LF13	2002/10- 2006/09	390	530	Euro 4	12.8	6	24
MAN	TGA 35	TGA 35.310 FFD	D 2876 LF13	2004/06- 2006/03	390	530	Euro 4	12.8	6	24
MAN	TGA 35	TGA 35.310 FFD	D 2876 LF13	2004/07- 2004/10	390	530	Euro 4	12.8	6	24
MAN	TGA 35	TGA 35.310 FFD	D 2876 LF13	2004/07- 2004/09	390	530	Euro 4	12.8	6	24
MAN	TGA 35	TGA 35.310 FFD	D 2876 LF13	2004/08- 2006/03	390	530	Euro 4	12.8	6	24
MAN	TGA 35	TGA 35.480 FFD	D 2876 LF12	2003/07- 2006/03	352	480	Euro 4	12.8	6	24
MAN	TGA 35	TGA 35.480 FFD	D 2876 LF12	2003/09- 2006/09	353	480	Euro 4	12.8	6	24
MAN	TGA 35	TGA 35.530 FFD	D 2876 LF13	2004/06- 2006/03	390	530	Euro 4	12.8	6	24
MAN	TGA 35	TGA 35.530 FFD	D 2876 LF13	2004/07- 2004/10	390	530	Euro 4	12.8	6	24
MAN	TGA 35	TGA 35.530 FFD	D 2876 LF13	2004/07- 2004/09	390	530	Euro 4	12.8	6	24

Website: www.truckfuelinjection.com

75-

www.truckfuelinjection.com

truck fuel injec	tion					.,				
MAN	TGA 35	TGA 35.530 FFD	D 2876 LF13	2004/08- 2006/03	390	530	Euro 4	12.8	6	24
MAN	TGA 37	TGA 37.480 VF	D 2876 LF12	2004/08- 2006/09	353	480	Euro 4	12.8	6	24
MAN	TGA 37	TGA 37.530 VF	D 2876 LF13	2003/06- 2006/09	390	530	Euro 4	12.8	6	24
MAN	TGA 40	TGA 40.480 DF	D 2876 LF12	2004/10- 2006/03	353	480	Euro 4	12.8	6	24
MAN	TGA 40 t	TGA 40.480 FD- WW	D 2876 LF12	2004/11- 2009/03	353	480	Euro 4	12.8	6	24
MAN	TGA 40	TGA 40.480 FD- WW	D 2876 LF25	2006/07- 2009/03	353	480	Euro 4	12.8	6	24
MAN	TGA 41	TGA 41.480 FFD	D 2876 LF12	2003/05- 2006/09	353	480	Euro 4	12.8	6	24
MAN	TGA 41	TGA 41.480 FFD- WW	D 2876 LF12	2003/06- 2009/03	353	480	Euro 4	12.8	6	24
MAN	TGA 41	TGA 41.480 FFD- WW	D 2876 LF25	2006/07- 2009/03	353	480	Euro 4	12.8	6	24
MAN	TGA 41	TGA 41.530 FFD	D 2876 LF13	2003/07- 2004/09	390	530	Euro 4	12.8	6	24
MAN	TGA 41	TGA 41.530 FFD	D 2876 LF13	2004/05- 2004/09	390	530	Euro 4	12.8	6	24

1.4. 0445120044 Injector Parameter

Adaptation System: Common Rail System

Injector Series: 120 Series

Parameter Performance: CRIN1-14/16

Matching Accessories: Gasket F 00R J02 175 (7.73*14.36*1.49)

Injector Type: Electromagnetic Injector
Support System Maximum Pressure: 1600
Vehicle Configuration Information: MAN

1.5. 0445120044 Injector Specifications and Dimensions

Injector Size: 21.5cm*4 cm *4 cm = 344cm3 (L*W*H=V)

Injector Net Weight: 0.55kg

Gross Weight: 0.6kg

Injector Quality: China Made New

Package Size: 28cm*7 cm *7 cm = 1372 cm³ Injector Type: Diesel Common Rail Injector

MOQ: 4 Pieces

1.6. 0445120044 Injector Customized Service

(1) Injector Customized Service: Shumatt support shell lettering, logo engraving, injector internal packaging, injector external packaging and labels, etc. Customized service, but the quantity of customized items must meet the demand of OEM manufacturers. The customized items' quantity requirement is as below,

(2) Injector Customized Service Requirements:


The purchased of customized injector are not less than 10 pieces.

Customized injector packages no less than 1000 pieces.

Customized products involve the need of specify logo, the OEM manufacturer needs to provide trademark authorization and the sample of logo image file.

• Once the customized fuel injector is sold, it cannot be returned or exchanged if there is no quality problems.

(3) Customized Items List




1.7. 0445120044 Injector Packing List and Package Size

(1) Injector Spare Parts List

No.	1	2	3		
Image	shunt (C)	0	0		
Name	Fuel Injector	O-Ring	Gasket F 00R J02 175		
Description Fuel injector part number: 0445120044		Ensure to meet the standard of the sealing performance between the injector and the engine	Made of brass, used to ensure the tight fit between the injector cap end and the engine		
No.	4	5	6		
Image					
Name	Nozzle Protective Cover Cap	Injector House Protective Cover Cap	Solenoid Valve Protective Cap		
Description	Protect nozzle holes from being polluted and blocked	Protect oil inlet from being polluted and blocked	Protect the solenoid valve body and terminals from being damaged by external forces		
No.	7	8	9		





Minors are forbidden to use the fuel injector assembly, O-ring, gasket, nozzle protective cover, fuel injector house protective cover, solenoid valve protective cover, VCI anti-rust bag, and air bubble bag to avoid personal injury.


• O-ring and gasket are disposable installation accessories, and need to be replaced for re-installation.

⚠ The nozzle protective cover, the injector house protective cover, and the solenoid valve protective cover are recyclable accessories that can be reused.

A VCI anti-rust bags and bubble bags are non-degradable materials, please dispose of them properly after using.

⚠ The injector and the installation parts should be coated with appropriate sealing oil during installation.

(2) Injector Box Size



No.	Name	Injector Package Size (cm)
1	Injector Box	28*7*7

1.8. 0445120044 Injector Quality Control

(1) Injector Testing

All injector spare parts are tested for electrical characteristics, accuracy, high temperature, low temperature, withstand voltage, leakage, durability, and various working conditions.

(2) Injector Assembling

And the quality control of the injector production and installation process, our company strictly follows the standard product installation data and product installation steps to install, such as injector stroke test, injector solenoid valve tightening torque, injector nozzle tightening torque

(3) Injector Inspection

The factory inspection of the injector is undergone full inspection, random inspection, and batch inspection three inspections. Different brands of test benches are used to test the same fuel injector for a total of no less than three times for factory inspection, and the fuel injector installation testing environment are progressed in dust-free workshop.

1.9. 0445120044 Injector Testing Standard and Certificate

We can provide the factory quality inspection test report of each injector to ensure that each injector delivered meets the engine performance indicators.



1.10. 0445120044 Injector Warranty Instructions

(1) Product Warranty Conditions and Instructions

1) It is necessary to provide pictures, videos, or test reports detected by the injector inspection equipment when the injector is abnormal during use as evidence to feed back to the salesman.

Abnormal conditions are properly explained such as: 1.Smoke, 2. Engine shake, 3. Difficulty starting the engine, 4. Engine noise, 5. oil leakage etc.

(2) Injector Warranty Coverage

- 1) Within 15 days after customer receives the 0445120044 injector, if there is a performance failure and the product has no appearance damage, customer can choose to replace it or repair it;
- 2) If the 0445120044 injector has performance problems during the warranty period (3 months), and it is confirmed that it is product's problems after testing, you can contact our salesmen to replace the same model or a reworked product with the same performance for free;
- If the injector house has obvious scratches, it can only be repaired and it will be returned as it is if the

© 2023 Shenzhen Shumatt Technology Co., Ltd

product is confirmed to be fault-free.

A Tips: For products not covered by warranty, our company can provide paid maintenance services. For

products after paid repaired, the same performance problem will have a free warranty period within 3 months from the date of repairing.

(3) Injector Out of Warranty Coverage

- 1) The warranty period has expired.
- 2) Injector failure caused by high temperature, high pressure, humidity, rain and snow, saline-alkali land, earthquake, and used in abnormal environment.
- Customer disassembles or repairs the injector personally resulting in damage to the injector. 3)
- 4) Injector damage caused by man-made reasons (throwing, strong magnetic field magnetization, set fire).
- Injector failure or injector damage caused by non-injector design, technology, manufacturing, quality 5) and other issues.
- Injector failure due to system pressure exceeding system approved pressure. 6)
- 7) Injector failure caused by system voltage exceeding approved voltage.
- Injector failure caused by impurities (water, lead, aluminum powder, iron powder, sulfide) in the system 8) fuel exceeding the standard requirements.
- Injector failure caused by not installing according to the tightening torque specified in the vehicle engine 9) maintenance manual (the tightening torque is too large or too small).
- 10) Injector failure caused by not following the installation angle specified in the vehicle engine maintenance
- 11) Injector failure caused by not following the cleaning requirements specified in the vehicle engine maintenance manual.
- 12) Injector failure caused by failure to replace consumable parts as specified in the vehicle engine maintenance manual.
- 13) Injector failure caused by not complying with the intake system fit clearance and exhaust system fit clearance requirements specified in the vehicle engine maintenance manual.
- 14) Failure to replace the consumable parts and the fitting clearance of the oil inlet system pipeline and the fuel injector connection in accordance with the fuel intake system specified in the vehicle engine maintenance manual.

1.11. 0445120044 Injector Manufacturer

Injector manufacturer: Shenzhen Shumatt Technology Co., Ltd

2. 0445120044 Injector Technical Support

2.1. 0445120044 Injector Part Number Location

1) E.g.: The injector part number see as follows




No.	Name
	brand, logo, part number,
A	series number
В	nozzle part number

2.2. 0445120044 Injector Application Scenarios

Common rail system is an oil supply method refers to the diesel oil from the fuel tank sucked out by the

gear pump through the oil-water separator and the gear pump to diesel fine filter, high-pressure pump, common rail pipe, and fuel injector, all together with the closed-loop fuel supply system composed of sensors and ECU that completely separates the generation of injection pressure and the injection process from each other.



Pic No. 1

No.	Name	No.	Name	No.	Name	No.	Name
1	Tank	5	Common Rail Pressure Sensor	9	Engine Crankshaft Sensor	Α	High Pressure Oil Circuit
2	Diesel Filter	6	Common Rail Pipe	10	Camshaft Sensor	В	Low Pressure Oil Circuit
3	High-Pressure Pump	7	Injector	11	ECU Electronic Control Unit		
4	Fuel Gear Pump	8	Accelerator Pedal				

2.3. 0445120044 Injector Installation

(1) 0445120044 Injector Installation Precautions:

The replacement of the fuel injector must strictly follow the electrical system, the approved pressure of the low-pressure fuel intake system, the approved pressure of the high-pressure fuel circuit system, and fuel system replacement consumables requirements (including the low-pressure fuel circuit system filter and the high-pressure fuel circuit) specified in the vehicle engine maintenance manual,

A Replacement of wearing parts of the fuel system, cleaning requirements for the connection between the fuel system and the injector, the fitting clearance of the fuel injector connection, the installation angle and tightening torque of the injector, the fitting clearance of the intake system, and the fitting clearance of the

exhaust system to ensure the service life of the engine and the normal operation of the injector.

⚠ When installing the fuel injector on the engine, it is necessary to clean the engine block, cylinder head and other parts connected to the fuel injector, and ensure that there is no dust, carbon deposits, water, rust spots, etc.

⚠ Before installing, check whether the fuel injector nozzle gasket has been replaced and installed on the fuel injector.

⚠ When installing the fuel injector, apply lubricant between the fuel injector, fuel nozzle sealing gasket and O-ring.

Mithout replacing new gasket can lead to: deformation of the tight cap of nozzle, deformation of nozzle,



deformation of nozzle orifice, oil leakage and air leakage, which will cause serious damage to the fuel injector and nozzle to break and cause damage to the engine.

⚠ When installing the injector on the engine, please carefully check the components related to the installation of the injector, such as the injector pressure plate, screw, injector rod and other accessories are not deformed, and install it in strict accordance with the operation steps of the engine maintenance manual.

A It is forbidden to operate the bare injector for a long time in an environment with serious dust pollution and corrosion to iron products.



It is forbidden to operate the bare injector for a long time in a strong magnetic field environment.

2.4. 0445120044 Injector Reasons for Not Working Normally

- (1) There is air in the oil circuit of the engine fuel system.
- (2) Vehicle oil pump oil supply system is not normal.
- (3) Engine common rail system oil leakage or pressure limiting valve damage.
- (4) There is a short circuit, cutting out and poor contact in the wiring harness connected to the fuel injector of the vehicle.
- (5) The long-term placement of the injector causes the anti-rust oil to solidify, and the internal components are stuck or the oil holes are blocked.

A Before installing, carefully check whether other components in the common rail system except the fuel injector are damaged so as to prevent the fuel injector from not working properly after being replaced.

2.5. **0445120044** Injector Causes of Damage

Website: www.truckfuelinjection.com

- (1) Didn't operate properly according to engine maintenance manual during disassembly or installation, resulting in damage to the injector.
- (2) The fuel oil used for the vehicle does not meet the standard cause damage to the injector, such as: the water content in the fuel oil exceeds the standard, iron powder, aluminum powder, sulfide impurities exceed the standard, etc.
- (3) The engine is not regularly maintained according to the engine maintenance manual (please refer to the vehicle maintenance manual for the maintenance mileage). For example, failure to replace the lubricating oil of the engine system for a long time will cause abnormal wear of the engine, excessive exhaust gas volume or a large amount of carbon deposits inside the engine. The filter is not replaced during maintenance or the replaced filter cannot reach the original filter standard. all above reasons can cause damage to the injector.
- (4) The abrasion of the oil pump produces iron powder and aluminum powder enter the fuel injector and cause damage to the fuel injector.
- (5) The deformation and abrasion of fuel tank result in iron powder or aluminum powder entering the fuel injector and causing damage to the fuel injector.
- (6) The fuel injector is damaged due to replacement or adjustment of the relevant parts of the fuel injector. For example, the valve clearance does not meet the standard after the engine is repaired, the replacement or modification of the wiring harness connected to the injector fails to meet the original standard.
- (7) The engine is overheated and overloaded for a long time working results in damage to the fuel injector.

© 2023 Shenzhen Shumatt Technology Co., Ltd



- (8) The injector will be damaged naturally at the end of its working life.
- (9) The injector is magnetized (injector parts' magnetic exceeded) causing the injector to not work properly.

A Before replacing the fuel injector, please check the engine parts carefully according to the engine maintenance manual to avoid the fuel injector being damaged again after replacement.

2.6. 0445120044 Injector Technical Support Obtaining Methods

- (1) Injector Technical File, visit http://shumatt.com to get the technical file.
- (2) Injector Technical Videos

Facebook: Visit https://www.facebook.com/hison.li to get the technical videos, constantly follow can get more information.

YouTube: https://www.youtube.com/channel/UCByvYBx7VjV mAfxh Hu-aw to get the technical videos, constantly follow can get more information.

Shumatt: Visit http://shumatt.com to get the technical videos.

(3) Injector Information Query Software

TruckBook Parts EPC APP, Android/Apple App Store download and install, visit http://shumatt.com to get the download and installation tutorial

(4) Search The fuel injector test data through TruckBook Parts EPC APP.

3. 0445120044 Injector Purchase and Delivery

3.1. 0445120044 Injector Purchase Payment Term

Payment Terms: T/T, PayPal, Alipay, WeChat

Please contact our salesmen for specific payment information.

3.2. 0445120044 Injector Main Sales Markets

Injector main sales markets: Asia, Europe, North America, South America, Africa etc.

3.3. 0445120044 Injector Declaration Requirements

Shumatt can assist customers to provide the following documents for import customs clearance: contract, invoice, packing list, bill of lading, insurance policy, certificate of origin, etc.

3.4. 0445120044 Injector Shipping Ways

Destination in China areas: SF Express, Debon Express, the corresponding logistics company can be provided according to customer requirements in special cases.

Destinations out of China's areas: DHL, UPS, FedEx, TNT air, ocean or other shipping methods required by customers.

3.5. 0445120044 Injector Lead time

Lead time: Send out within 3-7 working days after receiving payment (Except for special products and special cases).

3.6. 0445120044 Injector Logistics Time for Destination Out of China's Areas

DHL Logistics Time:

Country or Region of Hong Kong, Other Countries or Departure China Regions of Asia	Australia and New Zealand	Europe	America	Other Countries
--	------------------------------	--------	---------	--------------------



China's Mainland	7 Days	7 Days	8 Days	8 Davs	8-12 Davs	7-10 Days
onnia o mannana	, 20,0	, 54,5	0 5 4 7 5	0 0 0,0	0 12 24,5	, 10 50,0

UPS Logistics Time: Country or Region of Departure: China's Mainland

Country of Destination	Estimated Arrival Time	Country of Destination	Estimated Arrival Time	Country of Destination	Estimated Arrival Time
Japan	3 Days	UK	5-7Days	Egypt	5-7 Days
Turkey	5-7 Days	Singapore	3 Days	Switzerland 5-7 Da	
Bahrain	5-7 Days	Latvia	7-10 Days	New Zealand	7-10 Days
Sri Lanka	5-7 Days	Thailand	3 Days	Austria	5-7 Days
Romania	5-7 Days	Vietnam	3-5 Days	Estonia	5-7 Days
Malaysia	3-5 Days	Israel	5-7 Days	Mexico	7-10 Days
France	5-7 Days	America	5-7 Days	United Arab Emirates	5-7 Days
Italy	5-7 Days	Netherlands	5-7 Days	Bengal	7-10 Days
Lebanon	5-7 Days	Philippine	3-5 Days	Greece	7-10 Days
South Korea	3 Days	Spain	5-7 Days	Myanmar 5-7 [
Canada	5-7 Days	Germany	5-7 Days	Saudi Arabia 7-10	
Portugal	5-7 Days	Australia	5-7 Days	South Africa 7-10 I	
Denmark	5-7 Days	Belgium	5-7 Days	Ukraine 7-10 [
India	7-10 Days	Qatar	7-10 Days	Poland 5-7 Da	
Indonesia	3-5 Days	Morocco	7-10 Days	Pakistan 7-10 Days	
Kuwait	7-10 Days	. 80 . 80 .		A . AA . A	

[▲] The logistics time is for reference only, subjects are according to the actual arrival.

3.7. 0445120044 Injector Packing

Domestic express packaging: Usually wrapped in waterproof scotch tape, such as picture No.2.



Pic No. 2

International express packaging: Wrapped with waterproof yellow tape After wrapping the black protective film, such as picture No. 3.



Pic No. 3

Pallet Shipping: Use fumigation free and recycling trays that meet export requirements, and use white wrapping protective film to wrap and bind with cable ties for the outside, such as picture No. 4, also, the products can be packaged according to customers' requirements.



Pic No. 4

⚠ The packing tray is made of plastic and can be recycled.

▲ Transparent tape, yellow tape, black wrapping protective film, white wrapping protective film are non-degradable materials, please dispose of them properly.

• Minors are prohibited from using transparent tape, yellow tape, black wrapping protective film, and white wrapping protective film to avoid personal injury.

4. 0445120044 Injector Storage Standard

(1) Choose a suitable storage place

The warehouse and cargo yard where the fuel injector is stored should be kept clean and dry, and away from the factory buildings that generate harmful gases and dust; do not mix with acid, alkali, salt and other substances; the storage place should have a good drainage system; the cargo yard should be flattened with gravel or furnace ash etc. to enhance the water permeability of the surface layer to keep the reservoir area dry.

(2) Strict requirements of warehousing

1) Strict inspections should be carried out when the fuel injectors are put into storage, the surface cleaning work should be done well to remove water traces, oil stains, ash and other dirt, remove the rust and do anti-rust treatment in time. Packaged injectors must be protected from damage.

(3) Keep the warehouse dry and preventing moisture

1) The relative humidity is usually below 70% for the fuel injectors placed in the room, and the corrosion of the fuel injectors is significantly reduced.



2) Injectors must be stored in the warehouse, and they are forbidden to store in the same warehouse with commodities with high water content.

(4) Stack Properly

- 1) After the injector is exposed to rain, the corrosion rate will increase significantly. The purpose of sealing is to isolate the injector from rainwater and humid air, so the warehouse window should be checked in time to avoid rainwater entering the warehouse
- If the fuel injector package is damaged, it should be repaired or replaced; when the package is damp, the packaging material should be dried; if the original anti-corrosion and oil applied at the factory is found to be damaged or dried up, it should be cleaned and re-applied oil in time.

It is forbidden to leave the injector exposed in the air for a long time.

It is forbidden to store acid, alkali, salt and other substances together with the injector.

The unpacked fuel injector must be rust-proof during secondary storage.

5. Company Information



5.1. Company Introduction

Chinese Name: 深圳市舒马特科技有限公司

English Name: Shenzhen Shumatt Technology Co., Ltd

Mob Phone/WeChat: +86-13410541523

☐ **HK Telephone**: +852-67653519

Telephone: +86-755-23215133

Email: ruby@shumatt.com



Website: www.shumatt.com

- Shenzhen Office: 11-12, Floor 14, Building 13, Qinchengda Building, Exit A, Honglang North Subway Station, Bao'an District, Shenzhen, China's Mainland
- Shenzhen Office: Exit C, Qiao Touxi Metro Station, NO. 66 Chongqing Road, Fuhai Avenue, Bao'an District, Shenzhen, China Mainland
- Hong Kong Office: Jianfa Street Industrial Zone, Tuen Mun, New Territories, Hong Kong, China
- After-sales Service Address: Please contact our salesmen to obtain and provide the corresponding product maintenance reasons (Reference: 1.10. 0445120044 Injector Warranty Instructions)

5.2. Contact Information

Name	WeChat/WhatsApp	Email					
Hison Li	+86-13410541523	hison@shumatt.com					
PS: www.truckfuelinjection.com's offical email is end with @shumatt.com							

6. Copyright Policy

The copyright of the technical documents " *CRIN1-14 Common Rail 0445120044 Fuel Injection PDF*" cited on this website (including but not limited to pictures, text, trademarks, Logos, videos, audios, fonts, designs, etc.) belongs to Shenzhen Shumatt Technology Co., Ltd. The distribution and dissemination of such content requires in accordance with the wishes of its copyright owner. This website (www.truckfuelinjection.com, hereinafter referred to as "this website") cannot provide anyone with any authorization related to such content.

All references on this website are subject to necessary review in accordance with the relevant laws and regulations of the People's Republic of China and the requirements of copyright owners. If due to ignorance or other reasons, there are errors in marking or improper use, please contact us through hison@shumatt.com, this website will correct it as soon as possible after we know it.